

**STEP 1: SPREAD GLUE WHILE PROTECTING
AGAINST MOISTURE AND SOUND.**

STEP 2:

STEP 3:



Other wood floor adhesives waste time and effort because they don't include barriers to protect against moisture and sound in one step. So you have to spread the glue, then the underlayment, wait for it to cure, then come back a day later and spread adhesive again before putting down the floor. Stauf gets it done in one easy step. It's all part of our formula. Plus there's no water, solvents, or isocyanates. So it won't damage the wood and it cleans easily without etching the surface.

For innovative MS polymer technology that saves time and money and materials, there's only one. Stauf One-Step SMP-960. No wonder so many installers stick with Stauf.

www.staufusa.com | 866.GLUEUSA



Stick with what works.